



Maintenance | After use | Omnilock WLC50 | 30054

Page: 1 of 1

Prerequisites before repair;



- Always act according to the instructions supplied with each tool.

Necessary special equipment;

1.



Inspect;

- Check the general condition of the device.
- Check the housing for cracks tears.
- Check the condition and function of the carrying strap.

2.



Inspect;

- Lift the cover of the USB-C charging port.
- Inspect the USB-C port for damages.
- Inspect if the cover fully seals off the USB-C port.

3.



Perform;

- Charge the device with a compatible USB-C charging device.